

NUKEPROOF



FITTING INSTRUCTIONS

1. Get tubeless ready wheel and apply tubeless rim tape if required
2. Fit tubeless valve (supplied in box)
3. Fit one side of the tyre
4. Insert ARD foam into tyre just like fitting a tube



5. Add normal quantity of sealant to the tyre
6. Fit second side of tyre starting opposite the valve, ensuring the tyre bead goes under the ARD foam and into the rim well



7. Remove valve core and inflate tyre to seat bead
8. Replace valve core and inflate tyre to normal riding pressure

ADVANCED RIM DEFENCE