



- SHOCK BOLT KIT
- BEARING KIT
- HARDWEAR KIT
- CABLE GUIDE KIT
- FRAME PROTECTION KITS
- HANGER KIT
- FRONT DERAILLEUR

RECCOMENDED TORQUE VALUES

PART NUMBER	TORQUE
SHOCK BOLTS	15 NM
SWING LINK	8 NM
MAIN PIVOT	11 NM
HORST LINK	8 NM
CABLE GUIDES	2 NM
HANGER	3 NM